

Guidelines for NON - CRITICAL CARE staff

Common vasoactive drugs

These drugs are used to maintain cardiovascular stability. The full guide to administration can be found on **BSUH infonet > intensive care unit > clinical guidelines > inotropes**

These drugs MUST

- be given via a central venous catheter.
- Be given via a 'dedicated' line (several vasoactives can run together in one lumen of a CVC) with a 2, 3 or 4 lumen connector.
- given via an ICU specific syringe driver – these allow you to change the rate without pausing the infusion. All ICU pumps have ICU or HDU spray-painted on them.
- Be 'double pumped' ie: when changing syringe, the old and new infusions run concurrently to prevent loss of infusion during change **UNLESS 'RAPID CHANGE-OVER' TECHNIQUE IS USED, DUE TO LACK OF AVAILABLE PUMPS**

These drugs MUST NOT

- be paused, stopped or disconnected suddenly – they have a short half-life and pausing/stopping/disconnection may cause rapid CVS deterioration or arrest **UNLESS 'RAPID CHANGE-OVER' TECHNIQUE IS USED, DUE TO LACK OF AVAILABLE PUMPS**
- be given as a bolus, or bolused via the pump – this could cause rapid CVS instability
- run with ANY drug other than a vasoactive drug

COMMON VASOACTIVES

- NORADRENALINE – vasopressor: causes vasoconstriction and used to improve BP
USES: sepsis, septic shock, severe hypotension not resolved with fluid
- ADRENALINE – inotrope: increases contractility, raises BP and HR
USES: sepsis, septic shock, severe bradycardia
- DOBUTAMINE – inotrope and vasodilator: increases contractility and reduces cardiac work
USES: cardiac failure, cardiogenic shock
- MILRINONE – inotrope and vasodilator: increases contractility and reduces cardiac work
USES: cardiac failure, cardiogenic shock
- METARAMINOL – vasopressor: causes vasoconstriction and raises BP
USES: severe hypotension – used as temporary measure until CVC/norad established

Guidelines for NON - CRITICAL CARE staff

Common vasoactive drugs

NORADRENALINE/ADRENALINE (1:1000)

PREP

- draw up DRUG - 4mgs/4mls (1mg/ml)
- add to 46mls 5% dextrose to make 50mls
- concentration is 80mcgs/ml

PRIME

- PRIME the line AND 3 or 4-way connector with drug and CLAMP line.
- Ensure both SYRINGE and LINE are labelled with drug, drug concentration and date

ATTACH

- Set syringe in PUMP, set rate, volume to be infused (VTBI) and PURGE line after unclamping
- ATTACH primed line to CVC

INFUSE

- Check rate and pump
- ensure all lines/connectors UNCLAMPED
- start infusion

SPECIAL NOTES ON NORADRENALINE:

- Once infusion rate is 10mls/hr or more, concentration of noradrenaline or adrenaline should be increased
 1. 8mgs/8mls in 42mls 5% dextrose = 160mcgs/ml
 2. 16mgs/16mls in 34mls 5% dextrose = 320mcgs/ml
 3. 32mgs/32mls in 18mls 5% dextrose = 640mcgs/ml

****STRENGTHS > 8mgs/50mls require EXPERT help to start and change – do not attempt without senior ICU nurse help!****

Guidelines for NON - CRITICAL CARE staff

Common vasoactive drugs

DOBUTAMINE 250mgs/50mls

PREP

- draw up DRUG - either 250mgs/50mls (NEAT)
- or 250mgs in 20mls and add to 30mls of 5% dextrose
- concentration is 5mgs/ml

PRIME

- PRIME the line AND 3 or 4-way connector with drug and CLAMP line.
- Ensure both SYRINGE and LINE are labelled with drug, drug concentration and date

ATTACH

- Set syringe in PUMP, set rate, volume to be infused (VTBI) and PURGE line after unclamping
- ATTACH primed line to CVC

INFUSE

- Check rate and pump
- ensure all lines/connectors UNCLAMPED
- start infusion

SPECIAL NOTES ON DOBUTAMINE:

- DOBUTAMINE has a longer half life than noradrenaline. It is safe to stop one infusion and start the next with a short gap in between

****dobutamine should not be started without assistance and supervision from a senior ICU nurse colleague****

Guidelines for NON - CRITICAL CARE staff

Common vasoactive drugs

METARAMINOL 10mgs/20mls

METARAMINOL is used only for short term or immediate BP support during severe hypotension – during intubation/procedures or whilst waiting for CVC and noradrenaline to commence

PREP

- draw up 10mgs DRUG and add to 19mls NaCL
- concentration is 500mcgs/ml

ADMINISTER

- administer via peripheral or central IV route
- dose usually 1-2mls as bolus, as directed by Dr

Guidelines for NON - CRITICAL CARE staff

Common vasoactive drugs

MILRINONE 10mgs/50mls

****MILRINONE is not commonly used – this should only be started after advice from ICU CONSULTANT and should only be commenced with SENIOR ICU NURSE help****

PREP

- Draw up DRUG - 10mgs in 10mls amp and add to 40mls 5% dextrose
- concentration is 10mgs/50mls - 200mcgs/ml

PRIME

- PRIME the line AND 3 or 4-way connector with drug and CLAMP line.
- Ensure both SYRINGE and LINE are labelled with drug, drug concentration and date

ATTACH

- Set syringe in PUMP, set rate, volume to be infused (VTBI) and PURGE line after unclamping
- ATTACH primed line to CVC

INFUSE

- Check rate and pump
- ensure all lines/connectors UNCLAMPED
- start infusion

SPECIAL NOTES ON MILRINONE:

- MILRINONE has a longer half life than noradrenaline. It is safe to stop one infusion and start the next with a short gap in between

****MILRINONE is not commonly used – this should only be started after advice from ICU CONSULTANT and should only be commenced with SENIOR ICU NURSE help****

Guidelines for NON - CRITICAL CARE staff

Common vasoactive drugs

'DOUBLE PUMPING'

'Double pumping' is done with adrenaline and noradrenaline, to prevent BP collapse during syringe changeover

The full guide to administration can be found on **BSUH infonet > intensive care unit > clinical guidelines > inotropes**

BASIC PROCEDURE

PREP & PRIME

- prepare drug as per instructions
- change IV line every 24hrs

ATTACH

- Set syringe in PUMP, set rate, volume to be infused (VTBI) and PURGE line after unclamping
- ATTACH primed line to CVC - ensure all clamps UMCLAMPED

DOUBLE PUMP

- START NEW infusion at same rate as the one about to end
- WATCH MAP and wait for sustained rise in MAP >10mmHg
- WEAN old syringe down in small increments until down to 0.5mls - then PAUSE old infusion
- WAIT for BP to stay stable BEFORE switching off old infusion

NORADRENALINE at concentrations >8mgs/50mls may take considerable time to 'double pump'

Guidelines for NON - CRITICAL CARE staff

Common vasoactive drugs

'RAPID CHANGE-OVER' TECHNIQUE FOR NORADRENALINE AND ADRENALINE IF 'DOUBLE-PUMPING' CANNOT BE USED DUE TO LACK OF AVAILABLE PUMPS

'Rapid change-over' should only be used for concentrations of 4mg/50mls or 8mgs/50mls. Above this, 'double-pumping' must be used.

prep

- Prepare DRUG as per norad/adrenaline flowchart
- RESET VTBI for NEW infusion whilst pump still running

swap

- GIVE BOLUS 0.1ml of infusion from OLD syringe
- QUICKLY remove OLD syringe and insert NEW syringe into pump
- QUICKLY PURGE to remove mechanical slack
- QUICKLY attach NEW syringe to giving set and press START

observe

- OBSERVE CLOSELY: you can expect BP to be labile during the -period, this may require some small titration of infusion in the 10minutes after swap-over, until BP stabilises.

ALL NON-ICU STAFF SHOULD DO THE 'RAPID CHANGEOVER' UNDER DIRECT OBSERVATION OF AN ICU

COLLEAGUE UNTIL THEY HAVE SUFFICIENT EXPERIENCE TO DO THIS WITHOUT DIRECT SUPERVISION.